


HOW TO USE YOUR DISHWASHER

Load your dirty dishes, cutlery, etc., in the dishwasher, using the racks to hold items in place.

When the dishwasher is full and you are ready to run a programme, add a dishwasher tablet to the dispenser, which is in the door of the machine.



Control Panel

Turn on the dishwasher [1].

Select your programme by pressing the P button [2]: the programme number will be shown in the LED display [3].

There are 7 options available:

1. Eco, 50 degrees, 4 hours
2. Intensive, 65 degrees, 2.5 hours
3. Normal, 55 degrees, 2.5 hours
- 4. Daily, 50 degrees, 1 hour 20 mins**
5. Delicate, 45 degrees, 1 hour 40 mins
6. Express, 50 degrees, 30 mins
7. Rinse, 10 minutes

If the dishwasher is not full, you can select the Half Load option [4] which lights up when selected; press it again to deselect.

You can delay the start time, if desired, by 1 to 12 hours: press button [5] and the LED indicator will show 1h, 2h, etc. To cancel the delay time, press button [5] repeatedly until no delay time is shown.

When you have selected all the options you want, press the start button [6] and close the dishwasher door.

For full instructions on how to use your dishwasher, scan this QR code.